




Basketball

EXIT Galaxy Backboard
Wall Bracket Kit For Dunk Rim






EXIT Galaxy Backboard Wall Bracket Kit For Dunk Rim




Basketball

EXIT Galaxy Backboard Wall Bracket Kit For Dunk Rim




1




x4




x4



2



3m05




⚠ WARNING!

Ensure that there are no overhead power lines within 20 foot (7m) radius of system location.


Stellen Sie sicher, es gibt keine Hochspannungsleitungen im Umkreis von 7m des Systems.

Zorg ervoor dat er geen hoogspanningskabels binnen een straal van 7m van het systeem zijn.

Assurez-vous qu'il n'y a pas de lignes électriques aériennes dans 7m du système.



3





4

Don't tighten the bolts and remain 5-6mm space.

Schrauben noch nicht anziehen und lassen Sie bitte 5-6mm Raum.

Draai de bouten nog niet vast en laat 5-6mm ruimte over.

Ne pas serrer les boulons et laisser de l'espace 5-6mm



Now tighten the bolts at the back.

Nun die Schrauben festziehen an der Rückseite.

Schroef nu de bouten aan de achterzijde vast.

Maintenant, serrer les boulons à l'arrière.



www.exittoys.com

Contact Information:

Dutch Toys Group B.V.
Edisonstraat 83
7006 RB Doetinchem, The Netherlands

info@exittoys.com
www.exittoys.com

EXIT Toys is part of:

SIMBA · DICKIE · GROUP

EXIT Toys is a registered trade mark of Dutch Toys Group